

CALL 800-480-6613

SALES
REPAIR

SERVICE
INSTALLATION



INTEGRATION
WARRANTY



FBH ARCHITECTURAL SECURITY
Commercial Doors and Hardware

A Series lock functions

ANSI A156.2 Series 4000 Grade 2




Non-keyed functions


Schlage ANSI
A10 **F75**

Passage latch


- Both knobs always unlocked.




Schlage
A25D
Exit lock
• Blank plate outside.
• Inside knob is always unlocked.
• Specify door thickness.




Schlage ANSI
A30D **F77S**
Patio lock
• Push-button locking.
• Turn inside knob or close door to release button and prevent lock-out.



Schlage ANSI
A40 **F76**
Bath/bedroom privacy lock
• Push-button locking.
• Can be opened from outside with small screwdriver.
• Turn inside knob or close door to release button.



Schlage ANSI
A43 **F79**
Communicating lock
• Turn-button in outer knob locks and unlocks knob and inside thumbturn.



Keyed functions

Schlage

A170

Single dummy trim

- Dummy trim for one side of door.
- Used for door pull or as matching inactive trim.

Outside/Inside



Schlage

A53

ANSI

F109

Entrance lock

- Turn/push-button locking: pushing and turning button locks the outside knob, requiring use of a key until button is manually unlocked.
- Push-button locking: pushing button locks outside knob until it is unlocked by key or by turning the inside knob.

Outside Inside



● 8 ORB

Schlage

A70

ANSI

F84

Classroom lock

- Outside knob is locked and unlocked by key.
- Inside knob is always unlocked.

Outside Inside



● 8 ORB

Schlage

A79

Communicating lock with blank plate

- Locked or unlocked by key from outside.
- Blank plate inside.

Outside Inside



● 8 ORB

Schlage

A80

ANSI

F86

Storeroom lock

- Outside knob is fixed.
- Entrance by key only.
- Inside knob always unlocked.

Outside Inside



● 8 ORB

Schlage

A85

ANSI

F93

Faculty restroom lock

- Outside knob is fixed.
- Entrance by key only.
- Push-button on inside knob activates visual occupancy indicator, allowing only the emergency master key to operate.
- Rotation of inside spanner button provides lock-out feature by keeping indicator thrown.

Outside Inside



●